



(844)278-03-48, (473)204-51-73, (343)384-55-89, (843)206-01-48,
(861)203-40-90, (391)204-63-61, (495)268-04-70, (846)206-03-16,
(831)429-08-12, (383)227-86-73, - - (863)308-18-15,
- (812)309-46-40, (845)249-38-78, (347)229-48-12
:
- rtx@nt-rt.ru
- rexant.nt-rt.ru

13-0001

UNI-T UT202

.....	200	/2	/20	/200	/600	±(0.8%+1)
.....	2	/20	/200	/600	±(1.2%+5)	
.....	2 A/20 A/200 A/400 A	±(1.5%+5)				
.....	2000	/2	0	/200	0	±(1%+2)
.....	-40 ... +1000 °C/-40 ... +1832	±(1%+6)				
3-	+	+	+	+	max	28
						(Max Hold) +
+						210 * 75.6 * 30
						1.5 * 2
						= 10



13-0002

UNI-T UT204

.....	400	/4	/40	/400	/600	(0.8%+1)
.....	4	/40	/400	/600	(1%+5)	
.....	40	/400	(2%+3)			
.....	40	/400	(2.5%+5)			
.....	400	/4	/40	/400	/4	(1%+2)
(Duty Cycle).....						0.1% - 99.9%
.....	10	-1				(0.1%+3)
3-	+	+	+	+	+	28
True RMS+						210 * 75.6 * 30
Data hold +						9
						= 10



13-0003

UNI-T UT205

.....	400	/4	/40	/400	/600	(0.8%+1)
.....	4	/40	/400	/600	(1.2%+5)	
.....	400	/1000	(2%+5)			
.....	400	/4	/400	/4	/40	(1%+2)
.....	4	/40	/400	/4	/40	(3%+5)
(Duty Cycle).....						0.1% - 99.9%
.....	10	-10				(0.1%+3)
4-	+	+	+	+	+	40
						210 * 75.6 * 30
						9
						= 10



(844)278-03-48,
(391)204-63-61,
- -

(473)204-51-73,
(495)268-04-70,
(863)308-18-15, -

(343)384-55-89,
(846)206-03-16,
(812)309-46-40,

rtx@nt-rt.ru
- rexant.nt-rt.ru

(843)206-01-48,
(831)429-08-12,
(845)249-38-78,

(861)203-40-90,
(383)227-86-73,
(347)229-48-12

13-0004

UNI-T UT206

.....	00	/	/	/400	/600	(0.8 96 +1)	
.....	4	/40	/400	/600	(1.2 % +5)		
.....	400	/1000	(2 % +5)				
.....	400	/4	0	/400	/4	/40	(1 % +2)
.....	4	/40	/400	/4	/40	/200	(3 % +5)
.....	40...	1000 °	(196 +3)				
(Duty Cycle):	0.1 %	- 99.9 %				
.....	10	... 10	(0.196 +3) 4-				
.....	40						
.....	210	75.6	30				
.....	9						
.....	= 10						



13-0005

UNI-T UT208

.....	6.6	/66	/600	(0.8 % +1)			
.....	6.6	/66	/600	(1.2 % +5)			
.....	66	/1000	(1.5 % +8)				
.....	66	/1000	(2 % +8)				
.....	600	/6.6	/66	/660	/6.6	/66	(1 % +2)
.....	4	/40	/400	/4	/40	(1 % +3)	
.....	-40 ...	+ 1000 °C/-40 ...	+ 1832 ...	(1 % +4)			
(Duty Cycle):	0.1 %	- 99 %				
4-	55					
.....	13-20						
.....	210 * 75.6 * 30						
Тип батареи	9 В Крона					
.....	= 10						



13-1304

M266F

.....	2/20/200	± 0.5 %	1000	± 0.8 %
.....	200	± 1.0 %	750	± 1.2 %
.....	200 A	± 2.5 %	1000 A	± 3.0 %
.....	± 1.0 %		
.....	± 2.0 %		



(844)278-03-48, (473)204-51-73, (343)384-55-89, (843)206-01-48, (861)203-40-90,
 (391)204-63-61, (495)268-04-70, (846)206-03-16, (831)429-08-12, (383)227-86-73,
 - - (863)308-18-15, - (812)309-46-40, (845)249-38-78, (347)229-48-12
 rtx@nt-rt.ru
 rexant.nt-rt.ru

13-1301

MS2000G

.....		1
.....		2 /20 /200 ±(0.5%+1), 1000 ±(1.0%+2)
.....		200 /750 ±(4.0%+5)
.....		200 A/2000 A ±(2.0%+5)
.....		200 /20 /2 ±(1.2%+2)
.....		2 ±(1.5%+5)
.....		-20 ... 750 ° ±(2%+2)
.....		2000
.....		2.7
.....		282 * 104 * 47
.....		503
.....		CAT.II 1000



13-1302

MS2015

.....		1
.....		600 /6.6 /66 /660 ±(0.5%+3), 1000 ±(0.8%+2)
.....		600 /6.6 /66 /660 ±(0.8%+3), 750 ±(1%+4)
.....		66 A/660 A/1000 A ±(2.0%+3)
.....		660 /6.6 /66 /660 /6.6 ±(1.0%+3), 66 ±(1.5%+3)
.....		66 /660 /6.6 /66 ±(4.0%+3)
.....		0.10 ±(1.5%+5)
.....		0.10 ±(1.5%+5)
.....		066 ±(0.5%+3)
.....		10 ... 90 % ±3.0 %
.....		-20 ... 1000 ° ±(2%+2)
.....		-4 * 1832 * ±(2%+4)
.....		6600
.....		40 /1.6"
.....		238 * 92 * 50
.....		390
.....		CE, CAT.III 1000



13-1303

M266C

.....		1
.....		3
.....		200 /2/20/200 ±0.5%, 1000 ±0.0%
.....		200 ±1.0 96.7 50 ±1.2 %
.....		20 ±4 96.200 ±2.5 96.1000 ±3 %
.....		200 0 /20 /2 ±1.0%
.....		0... 400 ±1.0 %, 400... 750 ±2.0 %



(844)278-03-48,
(391)204-63-61,
- -

(473)204-51-73,
(495)268-04-70,
(863)308-18-15, -

(343)384-55-89,
(846)206-03-16,
(812)309-46-40,
- rtx@nt-rt.ru
- rexant.nt-rt.ru

(843)206-01-48,
(831)429-08-12,
(845)249-38-78,

(861)203-40-90,
(383)227-86-73,
(347)229-48-12